




**RADIANT PANEL HEATER
INSTRUCTION MANUAL
MODEL : EA651**



**PLEASE READ CAREFULLY BEFORE USE AND SAVE THESE
IMPORTANT SAFEGUARDS**

PET OWNERS WARNING:

The health of some small pets including birds are extremely sensitive to the fumes produced during the first-time use of many appliances. These fumes are not harmful to humans but we recommended that you do not use your heater around birds and small pets during its initial use until the manufacturing corrosion coatings burn off.

info@matrixindustrialproducts.com

IMPORTANT INSTRUCTIONS

GENERAL

This radiant heater is designed to provide supplemental heat in small areas such as offices and may be used as an under desk heater. However, care must be taken to avoid blocking heater or covering with anything that could allow it to build up heat – See warnings.



WARNING



When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
3. Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) away from front of heater and keep them away from the sides and rear.
4. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
5. Always turn heater off at switch and unplug heater from outlet when not in use.
6. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
7. Do not use this heater outdoors.
8. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
9. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
10. Connect to a properly grounded, 3-prong outlet only. Do not connect the heater to extension cords, surge protectors, timers, direct breakers, or an outlet with other appliances connected to the same outlet. Risk of fire, overheat, malfunction, property damage, injury, or even death may result if not adhered to!
11. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
12. Check heater cord and plug connections. Faulty wall outlet connections or loose plugs can cause the outlet or plug to overheat. Be sure the plug fits tight in the outlet. Heaters draw more current than small appliances, therefore over-heating of the outlet may occur even if it has not occurred with the use of other appliances. If plug outlet or faceplate is HOT, discontinue use and have qualified electrician check/replace the faulty outlet.
13. Always plug heater directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
14. If this heater is to be used in damp areas such as basements or garages, a ground fault circuit must be provided.
15. Do not make holes in the heater. Damage to internal electrical components or electric shock hazards may occur and this will void your warranty.
16. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS

INSTALLATION INSTRUCTIONS

This heater operates in upright position only. Before using the heater, swing the supporting leg out to make the heater stand on the floor.




Figure 1

OPERATION INSTRUCTIONS

1. Heaters are provided with flexible cord with a grounded plug (as shown in Figure 1) and built-in ON/OFF switch. This heater is for use at 120 VAC only and the rated power is 160W
2. Occasionally a new heater will emit a slight "new smell" Odor during initial use. This smell should dissipate within the first hour of use.
3. Always unplug heater when not in use. When heaters are not to be used for an extended period of time, cord should be coiled and tied to prevent damage and heater should be stored in a safe location.

MAINTENANCE INSTRUCTIONS

1. If heater fails to operate or if heater or power cord becomes damaged, unplug and discontinue use. DO NOT attempt to repair the heater. There are no user-serviceable parts inside.
2. Heater may be cleaned using a damp cloth or sponge and a mild detergent. Never submerge or soak heater in water. Always turn heater off and unplug before cleaning. Heaters may be repainted if desired. Use only high temperature water based acrylic paints.